

## Cheque Deposit Kiosk

To provide hassle free and convenient banking services through alternate delivery channels to customer by leveraging Technology, Aplab has launched an innovative Self Service cheque deposit kiosk.



**C**onvenient 24 X 7 cheque deposit facility

**N**o need to stand in Queue or fill any deposit slip

**I**ntant receipt of cheque deposit with clear Image of the cheque

**I**ntegration to Cheque Truncation System

**S**ecure cheque collection box with lock and key

**C**heques are stacked in serial order

## Cheque Deposit Facility

Customer can deposit cheques by entering few details prompted by the system and he/she would get instant receipt with cheque image and date/time stamp. CTS compatible front, back and UV scanned images would be transferred to CTS server through backend server. This facility will help reduce the time taken for clearing process and there is no need of scanning /entering the cheque details by the branch/service branch staff as this machine is having the feature of capturing necessary details.

Where the CTS integration is not required, the machine works as cheque deposit box with instant receipt. Branch staff has to remove cheques from the machine (Onsite/Offsite) and send these cheques to service branch as per normal clearing by following existing guidelines. Account number of cheque will be printed on the backside of cheque.

### Process of Cheque Deposit

- Customer selects the cheque deposit menu.
- Machine asks the user to enter the A/C number in which the amount is to be credited.
- Machine displays name of the account holder which is fetched from the CBS and asks the customer to confirm.
- After confirmation, machine will prompt the user to insert the cheque.
- After processing of the cheque, machine allows depositing more cheques in the same account, if required by the user.

### Technical Specification

CABINET	Front service modular lobby model. MS Enclosure 18 Gauge.
PC	Dual Core 3.0GHZ, 2GB RAM,500GB HDD.
MONITOR	15" Touch screen ( SAW).
CHEQUE SCANNER	(CTS compatible)
Option 1	Low Volume Image scanner with front and Rear camera along with one line endorsement.
Option 2	High Volume/ heavy duty UV scanner with front and Rear camera along with one line endorsement printer, Auto Skew (Auto alignment), Auto Shutter.
RECEIPT PRINTER	3" high speed thermal printer with auto cutter, 200 mm/sec, 203 DPI.
DEPOSIT BOX	Serial Stacker Cheque Collection Box.



**Aplab** BANKING & RETAIL AUTOMATION DIVISION

**APLAB LIMITED**

Plot No. 12, TTC Industrial Area, Thane Belapur Road, Digha, Navi Mumbai - 400 708. India.

Email : kiosks@aplab.com, response@aplab.com