

Self Service Automatic Passbook Printer



Automated kiosk where in customer can print passbook on their own

No need to visit branch in working hours to print a passbook

Simple and convenient 24 x 7 passbook print facility

The kiosk automatically reads the account details from the magnetic strip of the Passbook, and fetches the account transaction to print on the passbook

Automatic page turning in forward and reverse direction

Automatic page and line number detection

Passbook retraction facility

Passbook Printing

Magnetic stripe passbook printing:

A unique solution which can automatically flip the passbook pages and prints on the exact page and line number on the passbook. This requires Magnetic stripe passbook which stores details like Account number or serial number, page/line number of passbook, in the secure magnetic stripe. When customer inserts passbook into the machine, the machine reads the magnetic stripe, validates customer and prints transactions fetched from the CBS. Customer just needs to insert passbook into the machine. Machine automatically turns the correct page so there is no chance of printing on wrong page or wrong line number.

Some of the salient features of this product are:

- Self Service Passbook Printer is a fully automated machine having the ability to auto flip, auto align and update the customer passbook without any intervention of branch staff or the customer.
- It is a specialized machine, where customer has to simply insert passbook with only cover page opened and thus it is very convenient for all strata of customers.
- Machine will automatically detect and flip the pages in forward or reverse direction and print on appropriate page/locations.
- Passbook used in kiosk is magnetic stripe based. It has a pre-printed number which is already stored in the magnetic stripe of the passbook and mapped with the customer's account.
- Simple and customer convenient process.
- No manual intervention or help of branch official required.
- Services available 24X7 (in e-lobbies and ATM cabins).
- Further, value additions like self mapping of passbook (by customers) at the kiosk without approaching the branch for issuance of subsequent passbook etc. are enabled to enhance customer experience.

Technical Specification

CABINET	Front service modular lobby model. MS Enclosure 18 Gauge.
PC	Dual Core 3.0GHz, 2GB RAM, 500GB HDD.
MONITOR	15" Touch screen (SAW).
PASSBOOK PRINTER	Fully Automatic Magnetic Stripe Based 24 PIN DOT Matrix Printer, Auto Page Flipping in forward and reverse direction, Automatic Page and Line number detection.



Aplab BANKING & RETAIL AUTOMATION DIVISION

APLAB LIMITED

Plot No. 12, TTC Industrial Area, Thane Belapur Road, Digha, Navi Mumbai - 400 708. India.

Email : kiosks@aplab.com, response@aplab.com