

### IntelliPrint AI+ Self Service Semi Automatic Passbook Printer

To provide hassle free and convenient banking services through alternate delivery channels to customer by leveraging Technology, Aplab has launched an innovative Self Service kiosk called barcode based passbook printing kiosk.



**L**ow cost passbook printing solution

---

**C**onvenient 24 x 7 passbook printing

---

**U**se of existing passbooks in circulation

---

### Key Features

- Self Service Passbook Printer, is a automated machine having the ability to update the customer passbook without any intervention of branch staff.
- Customer has to simply insert passbook with correct page opened.
- Machine will automatically read the barcode and fetch relevant data from server to print.
- Passbook used in this kiosk is barcode number based. It will bear a pre-printed number mapped with the customer's account.
- Existing passbook stationery which is in use can be utilized by just pasting a barcode sticker on back cover.
- Simple and customer convenient process.
- No manual intervention or help of branch official required.
- Services available 24X7 (in e-lobbies and ATM cabins).

### Technical Specification

CABINET	Front service modular lobby model. MS Enclosure 18 Gauge.
PC	Dual Core 3 GHz, 2 GB RAM, 500GB HDD.
MONITOR	15" TFT LCD Touch screen (SAW).
PASSBOOK PRINTER	24 Pin DOT Matrix Printer, Built in Dual Image Scanner to read barcode.



**Aplab** BANKING & RETAIL AUTOMATION DIVISION

#### APLAB LIMITED

Plot No. B-92, Road No. 27, Wagle Estate, Thane 400 604. India.

Tel : +91-22-62612000 Fax : +91-22-25823137

Email : kiosks@aplab.com, response@aplab.com